



nc  
nc  
DRIVE3  
/INDEX  
DRIVE0  
DRIVE1  
DRIVE2  
/HL  
/DIR  
/STEP  
/RD  
/WR  
/TRK0\_0  
/WRITE\_PROTECT  
/RD\_FDD  
/SIDE1  
nc

- IC1 - 7417
- IC2 - 74LS139
- IC3 - 74LS05
- IC4 - 74LS174
- IC5 - WD1793
- IC6 - 74LS367
- IC7 - 74LS161
- IC8 - 74LS08

PORT #FF		
Bit	Out	In
0	Drive 0	-
1	Drive 1	-
2	/MR	-
3	HLT	-
4	Side 1	-
5	-	-
6	/DDEN	DRG
7	-	INTRQ

Pin25 - ENMF musí být připojen k log 0 pro mechaniku 3 1/2" nebo 5 1/4".  
Pin25 must be connected to log 0 if you are using floppy drive 3 1/2" or 5 1/4".

Betadisk controller with SAB2793  
Podle Mikrobaze a dalsich zdrojů  
prekreslil Cugnus.

controller_sab2793	
5.4.10 10:09	
Sheet: 1/1	