



nc
 DRIVE3
 /INDEX
 DRIVE0
 DRIVE1
 DRIVE2
 /HL
 /DIR
 /STEP
 /WRD
 /WRG
 /TRACK_0
 /WRITE_PROTECT
 /RD_FDD
 /SIDE1
 nc

- IC1 - 7417
- IC2 - 74LS139
- IC3 - 74LS05
- IC4 - 74LS174
- IC5 - WD1793
- IC6 - 74LS367
- IC7 - 74LS161
- IC8 - 74LS08

Bit	Out	In
0	Drive 0	-
2	Drive 1	-
3	/MR	-
4	Side 1	-
5	-	-
6	/DDEN	DRQ
7	-	INTRG

Pin25 - ENMF musí být připojen k log 0 pro mechaniky 3 1/2" nebo 5 1/4".
 Pin25 must be connected to log 0 if you are using floppy drive 3 1/2" or 5 1/4".

Betadisk controller with SAB2793 Podle Mikrobaze a dalsich zdrojů prekreslil Cygnus.	controller_sab2793 5.4.10 10:09 Sheet: 1/1
--	---